IMPORTANT GUIDELINES

HOW TO ENSURE THE BEST PERFORMANCE FROM YOUR ELIA COFFEE & TEA MAKER

(for your safety and optimum performance, please read this guide carefully before use)

We appreciate your decision to purchase an Elia quality product. Please read the important guidelines below and overleaf. By following these guidelines, we are confident that your Elia product will give you top performance and optimum satisfaction for years to come. Thank you.

PLEASE TURN OVER



10 AINTREE ROAD PERIVALE, MIDDLESEX UB6 7LA TEL: +44(0) 20 8998 2100 FAX: +44(0) 20 8997 5596

HOW TO USE

- Before use, we recommend you pre-fill with hot water to warm the glass container. Dispose of the water when the container is warmed.
 This warming process ensures superior performance from your Elia product and helps keep the beverage hot for longer.
- Position your Elia Coffee & Tea Maker on a stable non-slip surface. Hold the handle firmly whilst removing the plunger. Place the
 plunger carefully to one side.
- For coffee, add two level tablespoons of course-ground coffee, for each 40z/12cl cup required, into your Elia Coffee & Tea Maker. For tea, add one to two heaped teaspoons of tea, dependent upon the strength of tea used and preferred taste, for each 40z/12cl cup required.
- For coffee, carefully pour close-to boiling water into the glass container. Make sure you only fill up to 2cm/1inch from the top. Slowly and carefully stir the hot coffee with a plastic spoon. Do not use a metal spoon. Carefully replace the plunger and lid onto the glass container, but do not press down immediately. Wait at least 4 minutes for the coffee to gain full flavour. For tea, conduct the same procedure, but add boiling water.
- Grip one hand firmly to the handle and with your thumb from the same hand holding the lid secure. Ensuring the pout is pointing away from you, press the plunger down. Should the plunger become difficult to push down, raise it back up by about 3cm/1 inch and press again. Never apply too much force.

HOW TO CLEAN

- Thoroughly rinse your Elia Coffee & Tea Maker before use. After use, always dismantle with care and clean all parts with a soft cloth in warm water and washing up liquid. Make sure all former contents are properly removed. After the product is thoroughly cleaned, rinse well in clean water and leave to drain and dry. The glass container may be safely placed into a dishwasher.
- Whilst unlikely, it may be necessary to remove stubborn stains from the glass container. Insert one dessert spoon measure of soda crystals, which can be purchased from a Supermarket, fill with hot water and leave overnight. Always rinse several times after this operation, making absolutely certain the glass container is clean.
- Do not use a wire brush or pot-scourer, for these will scratch the glass container and metal frame.
- Do not use polishing powder or cream cleaner, for these too will scratch the glass container and metal frame.

IMPORTANT PRECAUTIONS!

- For your safety, always treat your Elia Coffee & Tea Maker with great care. Whilst strong, always remember your Elia Coffee & Tea Maker includes a glass container.
- Always store your Elia Coffee & Tea Maker upright and in a safe place. Keep away from children.
- Always operate on a stable non-slip surface.
- Do not place your Elia Coffee & Tea Maker on any hot surface or attempt to heat contents from the exterior; such as in ovens, in microwaves or on hot plates.
- Hot liquids can be dangerous. Never forget this when filling with hot water, operating the plunger and pouring.
- This Elia Coffee & Tea Maker is for table-top use only. In order to avoid spillage, please keep upright at all times.
- When hot coffee or tea is contained in your Elia Coffee & Tea Maker, do not use in any mode of travelling, as this product is <u>only</u> for table-top purpose.
- Always grip the handle firmly whilst pressing down the plunger. Additionally, always hold the lid down securely in place with your thumb. Never apply too much force.
- Do not press the plunger down until the coffee or tea has blended with the hot water for at least 4 minutes.
- Never use the glass container when it is cracked.

To prevent dangerous scalding by hot water or a beverage, always ensure that the spout is pointing away from you.

Every Elia quality product, from the individual parts to the finished product and throughout the fully automated processes, undergoes a comprehensive series of stringent quality checks to ensure efficient and effective use and a long service life for you.



10 AINTREE ROAD PERIVALE, MIDDLESEX UB6 7LA TEL: +44(0) 20 8998 2100 FAX: +44(0) 20 8997 5596